



NOTES: The PTCR Start Assist wires must be removed. Only the 10 & 16K units will have these installed

1) Connect the Easy Start Orange wire **with** the existing run capacitor compressor start (S) orange wire

2) Connect the Easy Start Black wire **with** the existing compressor common (C) black wire on terminal position #3

3) Remove the compressor white run (R) wire from the run capacitor & splice it into the Easy Start Brown wire (There are two white wires on this run cap post position, make sure to chose the one that goes to the compressor, not terminal position #2)

4) Where you just removed the white wire in step 3, connect the Easy Start White wire

3

1

4