



**1. Before Easy Start installation!**

**All connectors used must be 600VAC rated!**  
**If present in your system all start component connections and wires need to be removed where you see a yellow X**

**2. Put Easy Start Black with compressor common on the start relay #5.**

**Or**  
**Remove the connections from #5 on the start relay and make a 3-way splice with Easy Start Black.**

**3. Put Easy Start Orange on the run-capacitor Herm (H) position with compressor start.**

**4. Remove compressor run [see red X] from the run-capacitor and Splice to Easy Start Brown.**

**5. Where you removed the last connection Put Easy Start White on the run-capacitor.**