

NOTES: Disconnect the wires and components with the yellow x's. The DDC circuit board is not touched during Easy Start installation.

- 1-Connect the Easy Start Black wire on the start relay #5 position with the other two existing black wires.
- 2-Connect the Easy Start Orange wire on the run capacitor blue wire herm post.
- 3-Remove the compressor run red wire from the run capacitor and splice it into the Easy Start Brown wire.
- 4-Where you just removed the red wire in step 3, connect the Easy Start White wire.