

Webasto 10k-16k FCF Platinum-

Connect EasyStart orange to C3(39 BN) side. Disconnect COMP R (38 BU) from XT-N (5WH) then connect 38 BU to EasyStart brown, directly. Note 48BU is still preserved on C3 to XT-N. Create a pigtail on the EasyStart black wire with a male and female connection and connect EasyStart black (with pigtail) to COMP K54(4) and COMP C (40 RD). Connect EasyStart white to XT-N on its block or via C3(48BU) side.

