



NOTES: Any optional components installed, marked with yellow x's, need to be removed before ES installation

1-Remove the YEL compressor run wire from the #23 contactor position & splice into the Easy Start Brown wire

2-Where you just removed the YEL wire in step #2, connect the Easy Start White wire behind the contactor screw

3-Connect the Easy Start Black wire behind the contactor screw with the #21 comp C BLK wire

4- Connect the Easy Start Orange wire with the H (herm) BLU run capacitor wire