



1-Connect the ES Black wire with the contactor T2 compressor C black wire

2-Connect the ES Orange wire with the run capacitor S white (or yellow) wire

3-Remove contactor T1 compressor R red wire & splice into the ES Brown wire

4-Where you just removed the red wire in step 3, connect the ES White wire

TO THERMOSTAT