

1) Temporarily remove the condenser fan blade and mount the EasyStart to the base pan with self-taping sheetmetal screws (5/8" long or less).

2) Temporarily remove the top half of this evaporator shell cover and route the EasyStart harness wires up through this narrow passage.

3) Make all of the wire connections in this tight electric box area.

