

NOTES: For Mach 8 style 1 black board with capacitors in the box

A-Remove the start capacitor yellow & red wires (Yellow X's)

B-Remove the PTCR & plug the remaining red wire from the run capacitor back into the board

1-Connect the Easy Start Orange wire with the run capacitor compressor start (S)

2-Make a 3-way splice with the compressor black (C) wire wherever there's room

3-Remove the compressor white run wire from the run capacitor and splice it into the Easy Start Brown wire

4-Where you just removed the white wire in step 3, connect the Easy Start White wire

