



1. Before Easy Start installation!

If present in your system all start component connections and wires need to be removed where you see a yellow X

2. Put Easy Start Black with (C) compressor common (BK) on the junction board using the open spade connection.

3. Put Easy Start Orange on the run-capacitor Herm (H) position.

4. Remove (R) compressor run (WH) from the run-capacitor and Splice to Easy Start Brown.

5. Where you removed the last connection Put Easy Start White on the run-capacitor using the spade connection that is now open.