

1. Put Easy Start Black with compressor common (BK) in a 3-waysplice.

2. Put Easy Start Orange on the run-capacitor Herm connection.

3. Remove compressor run (WH) form the **Run-capacitor and Splice to Easy Start Brown.**

4. Where you removed the last connection Put Easy Start White on the run-capacitor.

1/18/16 REVB