

Carrier 25HBC5 Heat Pump

(and other Carrier units with similar wiring)

1. Before Easy Start installation! **All connectors used must be 600VAC rated!**

If present in your system all start component connections and wires need to be removed where you see a yellow X

2. Put Easy Start Black with compressor common on the contactor behind the screwhead using a fork or ring terminal connector.

3. Put Easy Start Orange on the run-capacitor Herm (H) position.

4. Remove compressor run from the contactor [see red X] and Splice to Easy Start Brown.

NOTE: The wire between the contactor and the run-capacitor common remains untouched, unused and nothing connected at either end!

5. Where you removed the last connection Put Easy Start White on the contactor behind the screwhead using a fork or ring terminal connector.

